

About Compatible Lexmark CS421/CS521/CS622 Lexmark CX421/CX522/CX622/CX625 toner cartridges Same Series Number Using and Controlling

S/N# (Series Number): (every toner cartridge and box marked)


Warning

Because of a same S/N# (Series Number) toner cartridge can not be used on a same Lexmark CS421/CS521/CS622 Lexmark CX421/CX522/CX622/CX625 printer over 2 times

In order to ensure the new toner cartridge could be normally working on your machine, Please do reading as below important:

- 1\Before Opening or install this new Toner , Please Check the Toner's S/N# Serier Number if it is samse as before, or ever used a same S/N# one
- 2\Please do not use a Same S/N# (Series Number) Toner on the same machine over 2 times ! Otherwise it will be highly possible not working
- 3\If you find the new toner cartridge S/N series number is same as before, please do not open and use it, and please contact or return it back to the provider

Lexmark CS421/CS521/CS622 Lexmark CX421/CX522/CX622/CX625 Compatible Toner cartridge Series Number (S/N#) Checking and management



Every Carton:
Black toner : 36 pcs
C/M/Y toner :42 pcs

Every Carton inside has different series number toner cartridges, to make the provider has enough series nubmer toner cartridge to meet User's requirement



1. Every toner cartridge and it packing Box marked it's S/N#
2. Please do not sell or provide a same S/N (series number) toner cartridge to a same user's machines.
3. if the user receive or find the new series number toner cartridge is same as before he ever used S/N, please do not use it and please return it back to your seller or provider.